

Service Manual

K21, K25 Gasoline Engine

For use with FGC15N-FGC33N Chassis Service Manual.

99789-55120

FOREWORD

This service manual covers K21 and K25 Gasoline Engines installed in Mitsubishi Forklift Trucks and gives detailed maintenance and repair information. For your convenience the instructions are grouped by systems as a ready reference.

The long productive life of your forklift truck(s) depends on regular and proper servicing servicing consistent with what you will learn by reading this service manual. Read the respective sections of this manual carefully and familiarize yourself with all of the components before attempting to start a test, repair or rebuild job.

All descriptions, illustration, specifications, and serial numbers in this manual are effective as of the printing date of this manual. Mitsubishi Forklift Trucks reserves the right to change specifications or design without notice and without incurring obligation.

99789-55120

GROUP INDEX

·		
GROUP INDEX	Items	
GI GENERAL INFORMATION	HOW TO USE THIS MANUAL, PRECAUTIONS FOR SAFETY AND QUALITY, PRECAUTIONS, TIGHTENING TORQUE, SPECIAL SER- VICE TOOLS, ENGINE OUTSIDE DRAWINGS, MAIN SPECIFICA- TIONS, STANDARD AND REPAIR LIMIT, STAMPED LOCATION OF ENGINE NO., TROUBLE DIAGNOSIS	GI
MA MAINTENANCE	ENGINE MAINTENANCE	MA
ET ENGINE TUNE-UP	SPECIFICATIONS, TIGHTENING TORQUE, TROUBLE DIAGNOSIS, ENGINE INSPECTION AND ADJUSTMENT	ET
EM ENGINE MECHANICAL	PRECAUTIONS, ENGINE OUTSIDE DRAWINGS, MAIN SPECIFICA- TIONS, ADJUSTMENT VALUE, TIGHTENING TORQUE, TROUBLE DIAGNOSIS, SPECIAL SERVICE TOOLS, REMOVAL AND INSTALLA- TION OF ENGINE, ENGINE SERVICE	EM
EC ENGINE CONTROL	PRECAUTIONS, PREPARATION, DESCRIPTION, TROUBLE DIAGNO- SIS, BASIC INSPECTION, COMPONENT PARTS INSPECTION, PCV GAS RECIRCULATION DEVICE, ECM COMPONENTS	EC
LC ENGINE LUBRICATION & COOLING SYSTEM	LUBRICATION SYSTEM, ENGINE COOLANT SYSTEM	LC
EF ENGINE FUEL	EMISSION CONTROL SYSTEM, ENGINE OUTSIDE DRAWINGS, SYS- TEM DIAGRAM, UNIT LAYOUT, SERVICE DATA AND SPECIFICA- TIONS (SDS), LPG FUEL SYSTEM TROUBLE DIAGNOSIS, DISAS- SEMBLY AND ASSEMBLY OF FUEL SYSTEM, DISASSEMBLY AND ASSEMBLY OF INJECTOR HOLDER, DISASSEMBLY AND ASSEM- BLY OF VAPORIZER	EF
EE ENGINE ELECTRICAL	ADJUSTMENT VALUE, TROUBLE DIAGNOSIS, STARTER MOTOR, ALTERNATOR	EE